



COLOUR CODE	FARBKODE	CODE DE COULEUR	
YW	YELLOW	GELB	JAUNE
WT	WHITE	WEISS	BLANC
RD	RED	ROT	ROUGE
GY	GREY	GRAU	GRIS
BR	BROWN	BRAUN	BRUN
BLK	BLACK	SCHWARZ	NOIR
BL	BLUE	BLAU	BLEU
Y/G	YELLOW-GREEN	GELB-GRUN	JAUNE-VERT

Refers to Harness W10527343

- 1040=Secondary doorswitch Oven in off position with door closed
- 1050=Monitor doorswitch Herd abgeschaltet Tur geschlossen
- 1060=Primary doorswitch Four debranche porte ferme

Circ Diagram PHOENIX FC

W10525995