



Wiring Diagram



- B1 OVEN SELECTOR
- C1 OVEN THERMOSTAT
- E1 GRILL HEATING ELEMENT
- H1 LOWER HEATING ELEMENT
- K2 OVEN THERMOSTAT LAMP
- L1 OVEN LAMP
- M1 CAVITY FAN
- M2 COOLING FAN
- Y THERMOFUSE
- W MAINS TERMINAL BLOCK
- Z2 COOLING FAN THERMOLIMITER
- X1 EARTHING CABINET
- X9 EARTHING UPPER /GRILL H. E.

- 00 BLACK
- 09 WHITE-BLACK
- 11 BROWN
- 22 RED
- 29 WHITE-RED
- 33 ORANGE
- 44 YELLOW
- 45 YELLOW-GREEN
- 49 WHITE-YELLOW
- 55 GREEN
- 66 BLUE
- 69 WHITE-BLUE
- 77 VIOLET
- 88 BLUE SKY
- 90 GREY
- 99 WHITE

Wiring Diagram

	0	1	2	3	4	5	6			
P1-1		X	X	X	X	X	X			
P2-2		X								
P3-3			X	X	X		X			
P4-4			X	X						
P5-5			X		X	X				
P6-6					X	X				
P7-7				X		X	X			X
P8-8				X	X					X
B1 4619 615 18151	O									