



UP TO SERIAL NUMBER IH18J

- | | | | |
|-----------|-------------------|-----------|-------------------|
| I | Schema Elettrico | NL | Schema Elektrisch |
| GB | Electric Diagram | E | Esquema Eléctrico |
| F | Schéma Electrique | PT | Esquema Eléctrico |
| D | Schema Elektrisch | TR | Elektrik Şeması |



991.0363.209 H90_263 r1


- | | | | |
|-----------|-------------------|-----------|-------------------|
| I | Schema Elettrico | NL | Schema Elektrisch |
| GB | Electric Diagram | E | Esquema Eléctrico |
| F | Schéma Electrique | PT | Esquema Eléctrico |
| D | Schema Elektrisch | TR | Elektrik Şeması |



991.0363.209 H90_263 r1


FROM SERIAL NUMBER IH18K

- | | | | |
|-----------|---------------------|-----------|-------------------|
| I | Schema Elettrico | NL | Schema Elektrisch |
| GB | Electric Diagram | E | Esquema Eléctrico |
| F | Schéma Electrique | PT | Esquema Eléctrico |
| D | Schema Elektrisch | TR | Elektrik Şeması |
| PL | Schemat elektryczny | | |



SE_991.0557.046 - 181130 - H90_541 r1 - D0005310_01

- | | | | |
|-----------|---------------------|-----------|-------------------|
| I | Schema Elettrico | NL | Schema Elektrisch |
| GB | Electric Diagram | E | Esquema Eléctrico |
| F | Schéma Electrique | PT | Esquema Eléctrico |
| D | Schema Elektrisch | TR | Elektrik Şeması |
| PL | Schemat elektryczny | | |



SE_991.0557.046 - 181130 - H90_541 r1 - D0005310_01